#### **APPENDIX D**

#### SUMMARY OF THE RAPID SEISMIC ANALYSIS PROCEDURE

#### **D-1.** Introduction

This appendix summarizes the rapid seismic analysis procedure (RSAP) developed by the Naval Civil Engineering Laboratory (NCEL) for the Naval Facilities Engineering Command (NAVFA-CENGCOM). The RSAP is preceded by computer and on-site screening at which time site hazards are identified. The RSAP is intended to identify buildings that are either liable to be severely damaged or only lightly damaged. It is a further screening tool. A complete description of this procedure is given in the NCEL Technical Memorandums TM No. 51-78-02 and TM No. 51-83-07. Examples showing the analysis of a steel and a concrete building are given in paragraph D-9.

#### D-2. Background

The RSAP was initially developed by John A. Blume & Associates in a pilot study of a relatively large number of buildings at Puget Sound Naval Shipyard in 1973. The procedure was formalized by NCEL.

- a. Seismic investigation of an activity. The seismic investigation is divided into two phases. In Phase I the selected buildings at the activity are analyzed approximately by RSAP. Phase I parallels chapters 2, 3, and 4 of this manual. Those buildings found to be inadequate to Phase I are analyzed in detail in Phase II to determine the degree of strengthening required and to estimate costs of upgrading. Phase II parallels chapters 5, 6, and 7 of this manual.
- b. RSAP. The main purpose of the RSAP is to identify those buildings that may be susceptible to severe damage. The major steps of the RSAP are shown in table D-1. The procedure has the same development roots as the procedures covered by chapters 2, 3, and 4 of this manual. The major modifications that NCEL made to the basic rapid analysis procedure follow:
- (1) Systemization of the analysis of the facility inventory assets at a Naval installation.
- (2) Development of the response spectra for the design earthquakes. This procedure has since been formalized by the Tri-Services Committee and is covered by NAVFAC P-355.1 (e.g., SDG).
- (3) Automation of computation of shear stiffnesses for concrete or masonry buildings, the first mode shape and natural period of multi-story buildings, and estimation of building damage from

the response spectra.

- (4) Enhance the RSAP with the following modifications:
  - (a) Criteria for field screening.
- (b) Criteria for eliminating buildings from further investigation in the rapid analysis.
- (c) Modified criteria for determining structural properties including damping values, natural periods and base shear capacities.
- (d) Modified criteria for determining the site demand from the response spectra at the ultimate base shear capacity for certain systems.
- (e) Criteria to aid the selection of buildings for detailed analysis.
- (f) Criteria to aid in evaluating the adequacy of the lifeline utilities at a given Naval activity.

#### D-3. Selection of buildings

The selection procedures of the RSAP includes provisions for inventory reduction, field screening, gathering of structural drawings and calculations, a visual inspection of the selection buildings, and a cursory survey of the site geological hazards.

- a. Inventory reduction. A procedure and criteria are presented in the RSAP references to facilitate the selection of the buildings for the visual screening. With the issue of this manual, the RSAP criteria are superseded by the screening procedure of paragraph 2-3 of this manual.
- b. Field screening. The RSAP references recommend criteria for eliminating buildings from further investigation. These decisions are made after the brief survey to determine physical conditions and after a brief examination of construction drawings. The criteria are similar to those provided in paragraph 3-2 of this manual.
- c. Visual inspection of selecting buildings. A final visit is made to verify that buildings are built as shown on the drawings, especially the lateral-force resisting elements. This step of the RSAP is similar to the first two steps of the preliminary evaluation described in paragraphs 4-2a and 4-2b of this manual.
- d. Site geological hazards. During the site visits, a cursory survey should be made of the potential seismically-induced geological hazards based on the available geologic subsurface information. These hazards include faults and fault rupture, liquefaction, landslide and lateral spreading, ground cracking, compaction settlement, tsunami, and seiches.

#### TM 5-809-10-2/NAVFAC P-355.2/AFM 88-3, Chap 13, Sec B

Table D-1. Major steps of the Rapid Seismic Analysis Procedure (RSAP)

#### **Preliminary**

- o Visual survey of the lifeline utility system.
- o Screening.
- o Selection of buildings.

#### <u>RSAP</u>

- o Determination of the site elastic response spectra.
- o Determination of the structural properties at yield and ultimate levels for the transverse and longitudinal directions.
- o Estimation of damage from the structural capacities and demands from the response spectra.

#### Follow-Up

- o Selection of buildings for detailed analysis.
- o Follow-up investigation of site hazards.

#### D-4. Determination of response spectra

Site specific elastic response spectra for single degree-of-freedom systems are determined in accordance with the procedures given in the SDG, chapter 3, appendix C and appendix D. The NAV-FAC ground motion criterion for the RSAP is a maximum ground acceleration having a 20 percent probability of exceedence in 50 years. (Note, this differs from the provisions in this manual, which specifies EQ-II. EQ-II has a 10 percent probability of not being exceeded in 100 years.)

a. Sample response spectra. Figure D-1 shows the resulting response spectra for an intermediate soil site with a maximum ground acceleration of 0.25g. The curves in the figure are used for determining the seismic demands (loading) on the buildings. These spectra are used for the examples of the RSAP given in paragraph D-9.

b. Acceptable capacities. Buildings with spectra acceleration capacities at ultimate that satisfy the site demands at ultimate according to the ground motion criterion are considered fully acceptable. Those buildings whose spectral acceleration capacities at ultimate are 75 percent of the demands at ultimate are considered marginal.

c. Variation in force levels. It is recommended that damage estimates be made for a few force levels below and above the 80 percent/SO year level. These estimates provide a profile of the expected seismic response of the building. This

recommendation is similar to those in paragraph 4-2d(6) of this manual.


# D-5. Determination of structural properties at yield and ultimate levels

The damping values, the natural periods, and the base shear capacities are determined for the transverse and longitudinal directions of the building.

a. Damping values. The assumed damping values used in the RSAP are given in table D-2.

*Table D—2. Damping values* 

	Percent of	Critical
<u>Type</u>	<u>Yield</u>	<u>Ultimate</u>
Steel	5	10
Concrete	5	10
Wood	10	20
Masonry	5	10



D-3

Figure D-1. Site response spectra for a Naval activity in southern California

#### TM 5-809-10-2/NAVFAC P-355.2/AFM 88-3, Chap 13, Sec B

(Note, these vary from the values given in table 4-2 of this manual.) The damping value increases from the yield to the ultimate level due to the inelastic deformation of the structural and non-structural elements of the building.

- b. Natural periods. Natural periods of the building in the transverse and longitudinal directions are determined from the following equations:
  - (1) Yield Level:

$$\begin{array}{cccc} \text{Empirical:} & T_Y = C & \left( \frac{0.05 \ h_n}{\sqrt{D}} \right) & (\text{eq } D\text{-}1) \\ \\ \text{Theoretical:} & T_Y = 2 \ \pi \ \sqrt{\frac{m}{k}} & (\text{eq } D\text{-}2) \\ & \sum\limits_{i=1}^{n} \ w_i \delta^2 & \\ \\ T_Y = 2 \ \pi & (\text{eq } D\text{-}3) \end{array}$$

(2) Ultimate Level:

$$T_{U} = T_{Y} \sqrt{\frac{S'_{aY}}{S'_{aU}}} \qquad (eq D-4)$$

where  $h_n$  = height of building (ft)

D = width of building in the direction considered (ft)

C = a constant between 0.75 and 1.5 to account for building mass and stiffness

m = seismic mass

k = stiffness of the building in the direction considered

 $w_i$  = weight of the building at level 'i"

 $\delta_i$  = elastic deformation at level "i" using the applied lateral forces  $f_i$ 

f<sub>i</sub> = approximate lateral force distribution consistent with the assumed fundamental mode shape

 $\mu$  = ductility factor equal to ratio of maximum displacement to yield displacement

 $S_{\dot{\alpha}Y}$  spectral acceleration capacity of the building at yield level

 $S_{\dot{\alpha}U}$  = spectral acceleration capacity of the building at ultimate level

(3) Equation D-1 is obtained by multiplying equation 3-3A of NAVFAC P-355 (e.g., BDM) by the constant C to account for the different building masses and stiffnesses. Equation D-2 is the natural period for a single degree-of-freedom system.

(4) Equation D-3 is the Rayleigh equation 3-3

of the BDM. The weight of the building is approximated by assuming unit weights for the roof framing, floor framing, wall, actual live loads (if any), and other miscellaneous items.

(5) The natural periods of the building at the ultimate level,  $T_U$ , are computed from the periods at the yield level,  $T_Y$ , by using equation D-4. The range of the recommended ductility factors,  $\mu$ , are given in table D-3.

Table D-3. Ductility factors

<u>Type</u>	μ
Steel	4-6
Concrete	3-4
Wood	3-4
Masonry	2-3

- c. Base shear capacities. After reviewing the field survey notes and the construction drawings, rought sketches of typical plans and elevations of each building are made to determine the primary lateral-force resisting system or systems. The yield and ultimate base shear capacities of a building are computed by summing the contributions from the vertical lateral force-resisting elements of the building in the transverse and longitudinal directions and dividing the results by the seismic weight of the building. The horizontal lateral-force resisting elements such as beam, girders, floor and roof diaphragms are only considered indirectly in the analysis by examining the effectiveness of their connections to the vertical lateral-force resisting elements.
- (1) Yield capacity. The yield capacity of a building is defined as the lateral-force required to cause the significant yielding of the most critical, not necessarily the most rigid, component of the lateral-force resisting system.
- (2) *Ultimate capacity*. The ultimate capacity of a building is defined as the lateral-force required to cause yield initiation of the most flexible component of the lateral-force resisting system of the formation of a collapse mechanism.
  - (3) Examples.
- (a) A steel building with a lateral-force resisting system consisting of infill brick walls and X-

braces may behave as follows in resisting seismic forces. The brick wall and X-braces may act together in resisting the seismic forces until cracking of the brick wall is initiated. Then the X-bracing and columns (only after the yielding of the X-braces) will take more and more of the seismic loading until they fail.

- (b) For a reinforced concrete building with shear walls, the shear walls will resist most of the seismic loading until they have started to crack. Thereafter, the frames will start to resist on increasing portion of the loading. For reinforced concrete frame and/or shear wall and reinforced masonry buildings, the ultimate base shear capacity, C<sub>BU</sub>, is computed first. Then, the yield base shear capacity, C<sub>BY</sub>, is obtained by dividing C<sub>BU</sub> by a load factor 1.5.
- (c) Wooden frame buildings with shear panels will behave like the concrete frame and shear wall buildings.
  - d. Spectral acceleration capacities.
- (1) Before they can be used for estimating the earthquake damage, the base shear capacities  $C_{\rm BY}$  and  $C_{\rm BU}$  must be transformed to the spectral acceleration capacities  $S'_{\rm aY}$  and  $S'_{\rm aU}$  using the following equations:

$$S'_{aY} = \alpha C_{BY}$$
 (eq D-5)  
 $S'_{aU} = \alpha C_{BU}$  (eq D-6)

(2) The constant a in the equations depends on the mode shape and mass distribution. The great majority of the Navy buildings are less than three stories high and can be classified as low-rise ( $\leq$  6-story). The  $\alpha$  constant for low-rise buildings ranges between 1.05 and 1.18, with the larger value for the taller buildings. For conservatism and simplicity, a is assumed to be one in most cases. (Note,  $\alpha$  a as used in this appendix is the inverse of a used in the SDG and in table 4-1 of this manual.)

#### D-6. Estimate of damage

Earthquake damage is estimated from the demands of the response spectra using the damping values, natural periods, and spectral acceleration capacities of the building.

- a. Damage assumption. Until yield capacity of the building is reached, damage is assumed to be equal to zero and ductility factor equal to one. When the ultimate capacity is reached, damage is assumed to be equal to 100 percent and ductility factor equal to the maximum value. For intermediate values of capacity, damage assessment is necessarily somewhat subjective and depends on many factors not amenable to analytical treatment. For the rapid analysis, damage is assumed to vary linearly between the yield capacity, S'<sub>aY</sub>, and the ultimate capacity, S'<sub>aU</sub>, as shown in figure D-2.
  - b. Damping assumption. Another assumption

required for estimating damage is the amount of damping during the response of the building. Damping is assumed to be a constant up to the yield capacity. Above yield, the damping increases because of energy absorption and dissipation from inelastic response. The damping values used in the rapid analysis were given in table D-2. Furthermore, damping is assumed to vary linearly between the yield and ultimate capacities of the building.

- c. Damage estimating procedure. procedure for estimating damage is based on the reconciliation of the site demands,  $S_{ay}$  and  $S_{aU}$ , and the spectral acceleration capacities of the building, S'<sub>aY</sub> and S'<sub>aU</sub>. The procedure is illustrated graphically in figure D-2. The spectral acceleration capacities of the building are denoted by the open circles at the natural periods shown. The corresponding site demands are denoted by the black dots. The intersection of the two lines defined by the two sets of points determines the estimated damage of 60 percent. This procedure is essentially the same as the capacity spectrum method of the SDG that is described in paragraph 4-2d of this manual.
- d. Modification damage to estimation procedure. After performing the rapid seismic analysis on a fairly large number of steel buildings and wooden buildings, comparisons of the RSAP damage estimates with damage observed in major earthquakes for buildings of similar construction indicated that the estimated damage were much higher than the observed. More realistic damage estimates were obtained by applying a reduction factor R<sub>II</sub> to the ultimate site demands for steel, wooden, and reinforced concrete and reinforced masonry buildings with better-than-average reinforcement detailing.
- (1) The reduction factor  $R_{\rm U}$  is used to account for energy absorption and dissipation from inelastic seismic response of the building during actual earthquakes not accounted for by the lengthening of the natural periods and increase in damping from the yield to the ultimate level. The following  $R_{\rm U}$  values are recommended:
  - (a) Steel Buildings:  $R_U = 5.0$ .
- (b) Wooden Buildings:  $R_U = 5.0$  for those buildings with a large number of interior partitions. For wooden warehouses and large-span wooden structures,  $R_U = 1.5$ .
- (c) Reinforced Concrete and Masonry Buildings:  $R_U = 1.5$  for those buildings with better than-average detailing than required by code during their design. Otherwise,  $R_U = 1.0$ .
- (2) An illustration of the effect of  $R_{\rm U}$  on the estimated damage is shown in figure D-2. With  $R_{\rm U}$  of 5.0, the estimated damage is reduced from 60 percent to 34.4 percent.




Figure D-2. Graphical illustration of damage estimation

- e. Combined building damage estimate. For each building, damage is computed for the transverse and longitudinal directions. To determine the combined damage for the building, it is assumed that one-third of the building depends on the lateral-force resisting system in each principal direction and one-third depends on both directions. That is, if a lateral-force resisting element required to provide seismic resistance in both directions is damaged by earthquake ground shaking in one direction, it is also damaged in the other direction. Combined damage for the building is obtained by taking two-thirds of the damage in the more critical direction and adding one-third of the damage in the other direction. For instance, if the damages are 60 percent and 30 percent in the transverse and longitudinal directions, the combined damage is 50 percent. (Note, this is essentially the same as paragraph 4-2d(5) of this manual.)
- Computer aided procedure for damage estimates. When computing damage estimates for many buildings and/or at many different ground acceleration levels, the computation is best done by a computer program. NCEL has developed computer program GEL 9 to do the calculations. The site identification, maximum site ground acceleration, digitized site response spectra, building identification, damping values, natural periods, and spectral acceleration capacities at the yield and ultimate levels for the transverse and longitudinal directions, and the replacement cost are input into the computer. The program computes the estimates damage and cost for the building at the maximum site ground acceleration. The damage cost is obtained by multiplying the estimated percent damage by the replacement cost. In addition, the program computes damage estimates for maximum ground accelerations between 0.05 and 0.50g at 0.05g increments. A sample output from the program for a steel building is given in table D-4.
- g. In general, the successful application of the rapid seismic analysis procedure demands experience in seismic design and construction and good engineering judgment.

# D-7. Selection of buildings for detailed analysis

Based on the results from the rapid analysis, the following guidelines are used in selecting buildings for detail analysis:

a. Buildings with greater than or equal to 60 percent combined damage under the maximum site ground acceleration would definitely require detail analysis.

- b. Buildings with greater than 30 percent combined damage may warrant detail analysis.
- c. Buildings with relatively poor structural connections may require detail analysis, even if the combined damage is less than 30 percent.
- d. Essential buildings and other structures that are required to remain functional during and after a major earthquake are analyzed in detail as for new buildings according to the criteria given in NAVFAC P-355.1 (e.g., SDG). Variance from the criteria is allowed only with the consent of the approving authority.

#### D-8. Visual survey of lifeline utilities

If an activity is to remain functional before and after an earthquake, the lifeline utility systems and the mechanical and electrical equipment must also remain functional. As a part of the rapid seismic analysis, a cursory survey is made of the lifeline utility system to determine its adequacy. The lifeline utility system at an activity includes:

- Energy
- Water
- Sewer
- Communication
- Transportation
- a. Network of utility elements. The effects from the failure of an utility element of the lifeline utility system is different than the failure of a building in an activity with many buildings. The failure of a building generally has little or no effect on the surrounding buildings, except in case of fire. By contrast, the utility elements are part of a network. The failure of one element can have an immediate effect on the function of the whole network. A discussion of lifeline utility problems in past earthquakes and solutions is given in NCEL TM No. 51-83-07.
- b. Administrative measures. The following administrative measures are recommended to minimize effects from earthquake damage to lifeline utilities on the mission of an activity:
- (1) Analyze and strengthen inadequate structures.
- (2) Provide adequate seismic bracing and/or anchorage to utility equipment and storage facilities (see chapters 3 and 10 of the BDM and chapter 6 of the SDG for examples).
- (3) Provides standby emergency power, water, materials, storage facilities, and alternative utility routes to insure rapid restoration capacity.
  - (4) Develop disaster recovery strategies.
- (5) Coordinate emergency planning with other military activities.

Table D-4. Sample output of damage estimate for a steel building from computer program CEL 9

DAMAGE ESTIMATES FOR VAMIOUS LEVELS OF EARTHQUAKE

DAMAGE ESTIMATE FOR VARIOUS BUILDINGS AT NST LONG BEACH

BLDG 132 MACHINE TOOL AND ELECTRO SHOP

	æ		5.000		5.000	
0F 0.25 G	SA SITE DEHAND	9	0.169		0.628 0.058	
CCELERATION	SA STA CAPACITY	99	0-130		0.150	
HOMINAL A	DAMP ING		9.10		0.03	
ESTIMATE FOR A	PERIOD	(sec)	2.430		0.620	
BUILDING PROPERTIES AND DAMAGE ESTIMATE FOR A NOMINAL ACCELERATION OF 0.25 G		FRANSVERSE DIRECTION	VIELD LEVEL	LONGITUDINAL DIRECTION	VIELD LEVEL ULTIMATE LEVEL	

RUILDING REPLACEMENT COST 8 17250900.
ESTIMATED TOTAL DAMAGE TO BUILDING 60.1 PERCENT ESTIMATED COST OF DAMAGE 8 10380682.

DAMAJE ESTIMATES FOR VARIOUS LEVELS OF MAXIMUM GROUND ACCELERATIONS

	•	DAMAGE EST	1 000 1	6165	8240	10380	•	1691	7149	8630	10380	11596	12490	13175	13717	14157
		COMBINED DAMAGE	PCMT	39.3	47.7	1.09	0.0	27.0	41.4	80.0	60.1	67.2	72.4	76.3	79.5	12.0
DIRECTION		DAMAGE	PCNT	59.0	11.6	80.3	0.0	40.5	62.1	13.4	80.3	95.0	89.4	90.9	92.9	94.5
LONGITUDINAL D	ACCEL	<b>UL1.</b>	G	0.030	0.040	0.053	0.011	0.021	0.032	0.042	0.053	190-0	0.074	0.085	0.095	0.106
LONG	SPECTRAL	VIELD	ဇ	0.352	0.477	0.628	0.126	0.251	0.377	0.502	0.628	0.754	0.879	1.005	1.130	1.256
1110M		DAMAGE	PCNT	0.0	0.0	19.8	0.0	0.0	0.0	3.2	19.8	31.5	40.3	47.1	\$2.6	57.0
ERSE DIRECTION	ACCEL	UL 1.	ی	100.0	100.0	0.302	0.000	0.001	100.0	0.01	0.002	0.002	0.002	0.003	0.003	0.003
TRANSV	SPECIAAL	VIELO	ی	0.095	0.128	0.169	0.034	9.068	0.101	9.135	0.169	0.203	0.237	1.210	0.304	0.338
		MAX GRND ACCL.	<b>.</b>	0 .1.4	61.0	0.25	3.05	01.0	0.15	0.20	0.25	0.30	0.35	04.6	S**0	0.50

#### D-9. Examples of the RSAP

The RSAP is illustrated by means of two examples. One is a steel building and the other is a concrete building. Table D-5 gives the response spectra data for both examples. Table D-6 gives the damage

estimates for the steel building and table D-7 gives the estimates for the concrete building. Figures D-3 and D-4 give the building descriptions and the RSAP calculations for the steel and concrete buildings, respectively.

Table D-5. Response spectra for steel building, example 1.

#### DAMAGE ESTIMATES FOR VARIOUS LEVELS OF EARTHQUAKE

# DAMAGE ESTIMATE FOR VARIOUS BUILDINGS AT NSY LONG BEACH DIGITIZED SITE RESPONSE SPECTRA FOR 0.25 G

PERIOD	PERCENI	OE CRI	TICAL DAMP	ING	
•	O PCNT 2	PONT	5 PCNT	10 PCNT	20 PCNT
0.00	0.25		9.25	0.25	0.25
	Q+25		0.25	0.25	0.25
0.05	<u> </u>	• •	3.30	0.23	9 • 26
0.10	le15	_7 • 6 4	0.43	0.38	0.32
<u> </u>		0•ላዲ	0.65	9.44	0 • 39
0.20	<u> </u>	<u> </u>	0.75	0.55	0.42
2.25		1.06	0.79	0.50	0.46
0.30		_1 • 0 7	0.32	9.63	0.48
0.35		_1 • 1 9	0.43	0.63	0.49
0 40		10 3	0.81	0.62	0-47
0.45		_1.05	0.77	9.58	0-44
<u> </u>		.1.00	0.74,	0.54	0.42
r.• 35		0.94	9.59	0.51	0.39
2-60		_ 1.438	9.54	2.48	0.37
<u>c-65</u>		0.32	0.61	0.45	0.34
0.70	1.29	., 0 • 7 7.	0.57	0 - 4 3	0.32
0.75	1.21	_7.72	0.54	0.41	0.30
0.80	_1.12	) • 68	9.51	0.39	0.29
0 <u>• 5 F</u>	1.01	7 • 5.3 .	7.49	0.75	0.26
0.96	0.93	0.53	0 - 4 4	0.34,	0.05
.1 • 04			0.41	0.31	₹•24
1.12	0.79	_ ) • <u>5</u> 0	0.39	0.29	0.23
1.20			0.36	0.27	0 • 22
1 -28	2.68	0 <u>• 4 4</u>	0.34	n.25	0.21
1.35	<u>       0                             </u>	0.42	9.32	0.25	0.20
1.44 1.52	0.61	. i) • 40	0.30	0.23	0.19
1.60	0.58	0 • 37	0.28	0.22	0.18
1.65	0.55	2.35	0.27	0.21	0.17
	0.53	0.34	0.25	0.20	0.17
1.76 1.84	0.51	0.32	0.24	9-19	0.16
1.84	0.48	0.31	0.23	0.13	0.15
	0.46	_0 • 3.0	0-22	0.18	0.14
2.00	0,44	0.28	0.21	0.17	0.13

Table D-6. Output for steel building, example 1.

DAMAGE ESTIMATES FOR VARIOUS LEVELS OF EARTHQUAKE

DAMAGE ESTIMATE FOR WARIOUS BUILDINGS AT NSY LONG BEACH

PIPE AND COPPER SHOP 8LDG 131

	Œ		5.000		000	
JF 0.25 G	SA SITE DEMAND	9	0.602		0.77	
SELERATION	SA STR CAPACITT	99	0.510		0.130	
NOMINAL ACC	DAMPING		0.0 0.10		0.00	
STINATE FOR A	P. R. 100	(326)	0.410		0.000	
BUILDING PROPERTIES AND DAMAGE ESTIMATE FOR A NOMINAL ACCELERATION OF 0.25 G		TRANSVERSE DIRECTION	TECO LEVEL	LONGITUDINAL DIRECTION	VIELD LEVEL ULTIMATE LEVE:	

65.1 PERCENT \$ 3428000. \$ 2231785. ESTIMATED TOTAL DAMAGE TO BUILDING BUILDING REPLACEMENT COST ESTIMATED COST OF DAMAGE

DAMAGE EST 1000 \$ COMBINED DAMAGE PCNF DAMAGE ESTIMATES FOR VARIOUS LEVELS OF MAXIMUM GROUND ACCELERATIONS 62.4 73.5.5 111.5 111.5 111.5 111.5 111.5 111.5 111.5 111.0 111.0 DAMAG: PCNT LONGITUDINAL DIRECTION SPECTRAL ACCEL TIFLD ULT. TRANSVERSE DIRECTION SPECTRAL ACCEL field ulf. 0.046 0.062 0.003 0.016 0.016 0.016 0.0113 0.1113 MAX GRND ACCL. 00.00 00.00 00.00 00.00 00.00 00.00 00.00 00.00 00.00

DAMAGE EST 1000 \$

Table D-7. Output for concrete building, example 2.

DAMAGE ESTIMATES FOR VARIOUS LEYFLS OF FARTHOUAKE

DAMAGE ESTIMATE FOR WARTOUS BUILDINGS AT NST LONG REACH

											DAMAGE ESTIMATES FOR VARIOUS LEVELS OF MANIMUM BROUND ACCELERATIONS			COMBINED DAMAGE	PCNT	0.0	o ·	1 • 1 •	B. «		9 C	1-16	0.001			0.001	) ) ) )
r	1	<b>«</b>			1.000		1.000		ACENT		UN GROUND	IRECTION		DAMAGE	PCRT	0.0	0 9	43.2	9 0		9 6		0001		9.00		) )
	OF 0.25 6	SA SITE DEMAND	9		0.409		0.372	4455000.	61-1. PERCENT	1612159.	S OF MAKER	LONGITUDINAL DIRECTION	1 ACCEL	urf.	و	0.262	0.356	994.0	460°0	0.187	0.281	****	96.0	***	0.749	245	60 7 60 100 100 100 100 100 100 100 100 100
	CELERATION	SA STR CAPACITY	9		0.320		0.340	*	SUILDING		RESUS LEVEL	LONG	SPECTRAL	41610	و	0.208	0.283	0.372	0.07	641.0	0.223	0 1 1 0	7100	- 44.0	0.595	0.570	-
	NOMINAL AC	DAMPING			0.00		0.00	EMENT COST	DAMAGE TO L	OF DAMAGE	ATES FOR VA	*		DAMAGE	PCN1	0.0	0.0	100.0	0.0	0	e .	ŗ	900		100.0	0.001	8 6 6 4
L:	TIMATE FOR A	PER100	(386)		3.160		0.070	BUILDING REPLACEMENT COST	ESTIMATED TOTAL DAMAGE TO BUTLDING	ESTIMATLU COST OF DAMAGE	AMAGE ESTIM	TRANSVERSE DIRECTION	ACCEL		ی	0.281	0.382	0.502	0.100	0.201	0.301	204.0	200.0	40.0	0.903	906.6	10001
MARINE MACHINE	D DAMAGE ES				VCL .		VÉL VEL	BUIL	1153	1183		TRANSV	SPECTAAL		٠	1.228	1.310	1.403	3.082	1.163	3 - 2 4 5	3.526	804.0	1.5.0	1.653	1.730	3.816
BLDG 1298 M4	BUILDING PROPERTIES AND DANAGE ESTINATE FOR A NONINAL ACCELERATION OF			TRANSVERSE DIRECTION	TIELD LEVEL ULTIMATE LEVEL	LCNGITUDINAL DIRECTION	TIELD LEVEL ULTIMATE LEVEL							MAX GAND ACCL.	3		91.0	0.25	60.0	0.10	51.0	07.0	22.0		00.0	54.0	05 • 6

Building 131 - Pipe and Copper Shop

## Building Data

One-story steel frame building Drown in 1940 122ft x 402ft in plan x 31.5ft high

## Construction

Laterally braced steel frames
Composition roof supported by steel trusses
and bracing.
Rivet connections

Foundation consists of concrete slab supported on concrete piles.

Lateral force resisting system :

Steel frames with vertical bracing in the longitudinal direction

### Beam- Girder System .

Beams :

6 - W 21 x 59 27 - W 24 x 74

Crane girders:

20 - W 30X 116


### Columns


22 - WIOX 33

22 - W 18 X 45

Sheet 1 of 7

Figure D-3. Example of steel building. (Sheet 1 of 7)





Sheet 2 of 7

Figure D-3. Example of steel building. (Sheet 2 of 7)

#### Weights

Spectral Acceleration Capacities Fy = 36. ks;

Columns 
$$h_{eff} = 15.1/2 = 7.5'$$

W 10 x 3 3

 $v_x = \frac{F_q S_{xx}}{h_{eff}(12\%)} = \frac{36.k : 1(35m^2)}{7.5'(12\%)}$ 

= 14.  $\frac{k}{col}$ .

$$U_g = \frac{F_a S_{yy}}{h_{eff} (12\%)} = 14.\frac{k(9.16)}{35.}$$

$$= 3.66 \frac{k}{col}$$

W 18×45

$$U_x = 14.\frac{k}{col} \left( \frac{79.0}{35.0} \right) = 31.6\frac{k}{col}$$

$$U_y = 14.\frac{k}{col} \left( \frac{9.32}{35.0} \right) = 3.73\frac{k}{col}$$

At yield:  
Long: 
$$V_{YCQ} = 22col.(3.66\%col. + 3.73\%col.)$$
  
 $= 162.6\%col. + 31.6\%col. + 31.6\%col.)$   
Trans.:  $V_{YCQ} = 22col.(14.\%col. + 31.6\%col.)$ 

Sheet 3 of 7

Figure D-3. Example of steel building. (Sheet 3 of 7)

At ultimate:

Diagonal Braces. Only effective in tension

Six sets of 23/2" x3" x 5/16".

Each set is connected by four 7/8" & rivets
in single shear.

$$A = 3.0 \text{ in}^2$$

Brace .

$$P_{\ell} = f_{y} A \left(\frac{40}{42.72}\right) = 36. ksi \left(3.0 \text{ m}^{2}\right) \left(\frac{40}{42.72}\right)$$

$$= 101.1 \text{ kg}$$

Four 78 0 rivets :

$$S_r = 4Af_v(\frac{40}{42.72}) = 4(\frac{\pi}{4})(0.876)^2(18.75kz)$$
  
 $\times(\frac{40}{42.72}) = 42.2\frac{k}{6}$   
Controls

Strength of the six diagonal broces:

Neglect contribution from siding.

Totals

At gield:  
Long.: 
$$S_{av} = C_{Bv} = \frac{253.2}{1961.8} = 0.13$$
  
Sheet 4 of 7

Figure D-3. Example of steel building. (Sheet 4 of 7)

Trans.: 
$$S_{aV_{t}} = \frac{1003.2^{k}}{1961.8^{k}} = 0.51$$

At ultimate:

Long.:  $S_{aU_{t}} = \frac{253.2^{k} + 162.6^{k}}{1961.8^{k}} = 0.21$ 

Trans.:  $S_{aU_{t}} = \frac{1203.8^{k}}{1961.8^{k}} = 0.61$ 

## Natural Periods

$$\frac{At \text{ yield}}{T_{Y}} = 2\pi \sqrt{\frac{m}{k}}$$

$$m = \frac{W}{3} = \frac{1961.2^{k}}{32.2} = 60.9^{k} - \sec^{2}/47$$

Column stiffnesses:

$$h_c = \sum \frac{12EI}{L^3}$$

Long: 
$$k_{c.l} = 2Z \left[ \frac{12.(30 \times 10^{3})}{(15.)^{3}(144)} \right] (36.5 + 34.8)$$
  
= 1,161. \( \frac{1}{4} \)

Trons.: 
$$k_{ct} = 22 \left[ \frac{12.(30.\times10^3)}{(15.)^3.(144)} \right] (171. + 706.)$$
  
=  $14.289.^{1}/47$ 

Bracing stiffness:  

$$k_{d1} = \frac{AE}{L} \left(\frac{40.}{42.72}\right)^{2} = \frac{3.(30.\times10^{3})}{42.72} \left(\frac{40.}{42.72}\right)^{2}$$

$$= 1847.0^{k}/4T / brace$$
Sheet 5 of 7

Figure D-3. Example of steel building. (Sheet 5 of 7)

$$k_{de} = 6 (1847.0 \text{ ft}) = 11.082 \text{ ft}$$

$$k_{de} = 6 (1847.0 \text{ ft}) = 11.082 \text{ ft}$$

$$k_{de} = \frac{11.082 \text{ ft}}{10.082 \text{ ft}} + 1.161. \text{ ft}$$

$$= 12.243 \text{ ft}$$

$$T_{ve} = 2\pi \sqrt{\frac{60.9 \text{ ft}}{12.243. \text{ ft}}} = 0.44 \text{ sec}$$

$$T_{ve} = 2\pi \sqrt{\frac{60.9 \text{ ft}}{14.289. \text{ ft}}} = 0.41 \text{ sec}$$

$$At \text{ ultimate}$$

$$Long : Only the column stiffnesses are effective$$

$$T_{ue} = 0.44 \sqrt{\frac{1.161.}{12.243.}} = \frac{1.43 \text{ sec}}{1.43 \text{ sec}}$$

$$T_{ue} = 0.41 \sqrt{\mu \left(\frac{5av_{e}}{5av_{e}}\right)} = 0.41 \sqrt{4/1.2}$$

Sheet 6 of 7

= 0.75 sec

Figure D-3. Example of steel building. (Sheet 6 of 7)

## Summary

	T(sec.)	Sa (9)
At Yield Long. Trans.	0.44 0.41	0.13
At Ultimate Long. Trans	1.43 0.75	0.21

The response spectra used to load the building is given in Table D-5.

Computer output for the building is shown in Table 0.6. The combined damage for the building at 0.25 g is 65.1%. Hence, the building requires strengthening. This can be accomplished by welding the existing diagonal brace connections and/or the installation of new diagonal braces.

Sheet 7 of 7

Figure D-3. Example of steel building. (Sheet 7 of 7)

## Building 129B - Marine Machine Shop

## Building Data

One-story reinforced concrete building with two mezzanines
Drawn in 1944
172 ft x 275 ft in plan x 34 ft high

### Construction

Reinforced concrete frames and shear walls. Built-up roofing over concrete roof slab. Concrete slab foundation

Lateral-force resisting system :

Reinforced concrete frames and shear walls.

#### Beams

### Columns


Sheet 1 of 6

Figure D-4. Example of concrete building. (Sheet 1 of 6)


#### Shear Walls

Exterior : 8 in. Thick with about 50% openings

: 6 in. thick with negligible amount of openings. Interior



PLAN



Sheet 2 of 6

Figure D-4. Example of concrete building. (Sheet 2 of 6)

## Weights

Roof

Beams 
$$\frac{16 \times 30}{144}(150 \text{pcf}) = 500 \text{ lb/ft}$$
  
 $\frac{500 \text{ lb/ft}}{25 \text{ ft spacing}} = 20 \text{psf}$   
Slab  $\frac{6}{12}(150 \text{pcf}) = \frac{76}{95} \text{psf}$   
Use  $100 \text{psf}$ 

Walls

1050 linear foot of tributary 15' high Bin. Thick wall.

Seismic Weight

Sheet 3 of 6

Figure D-4. Example of concrete building. (Sheet 3 of 6)

## Spectral Acceleration Capacities

## Assumptions :

- 1. Ultimate shear strength for concrete columns and shear walls = 100 ps;
  2. Only one-third of the column cross-sectional area is effective in resisting seismic shear forces.

### Columns

60 - 16" 
$$\times$$
 24" (Average = 15e) columns

 $A = 16 \times 24 = 384 \cdot \text{in} \cdot \text{lool}$ 
 $V_{cu} = 384 \cdot \text{in} / \text{col} \cdot (0.1 \text{ks}) / 3 = 12.8 / \text{col}$ 
 $V_{cu} = 60 \cdot \text{col} \cdot (12.8 \text{lool}) = 768 \cdot \text{k}$ 

### Sheor Walls

Long.: 
$$(550 \text{ ft})(12 \text{ in/ft})(8 \text{ in.})(0.5)$$
  
 $+ (25 \text{ ft})(12 \text{ in/ft})(6 \text{ in})(1.0)$   
 $= 28200 \text{ in.}$   
 $\times 0.1 \text{ ks.}$   
 $\times \text{wu}_q = 2820 \text{ k}$   
Trans.:  $(344 \text{ ft})(12 \text{ in/ft})(8. \text{ in.})(0.5)$   
 $+ (140 \text{ ft})(12 \text{ in/ft})(6. \text{ in.})(1.0)$   
 $= 26,529 \text{ in.}$   
 $\times 0.1 \text{ ks.}$   
 $\times \text{vswu}_t = 2659 \text{ k}$ 

Sheet 4 of 6

Figure D-4. Example of concrete building. (Sheet 4 of 6)

## Total Capacities

## At Ultimate

Long.: 
$$S_{au_{g}}^{i} = C_{eu_{g}}^{i} = \frac{2820^{k} + 768^{k}}{7095^{k}}$$

$$= 0.51$$

Trans.: 
$$Sau_{t} = C_{BU_{t}} = \frac{2659^{k} + 768^{k}}{7095^{k}}$$
  
= 0.48

## At Yield

Trans.: 
$$S_{ay_{t}} = \frac{0.48}{1.5} = 0.32$$

### Natural Periods

Long.: 
$$T_{Y_Q} = \frac{0.05 \, h_n}{\sqrt{D}} = \frac{0.05(22)}{\sqrt{276}} = 0.07$$

## At Ultimate

Sheet 5 of 6

Figure D-4. Example of concrete building. (Sheet 5 of 6)

#### Summary

	T (sec)	Så (g)
At Yield Long. Trans.	0.07 0.08	0.34 0.32
At Ultimate Long. Trans.	0.14 0.16	0.51 0.48

The response spectra used to load the building was given in Table D-5

The computer output for the building is shown in Table D-7. The damage Threshold is at a maximum ground acceleration of about 0.20 g. The estimated combined damage

at 0.25 g acceleration is 81.1%. Thus, the building is inadequate and requires strengthening, particulary in the transverse direction. This can be accomplished by thickening the

existing shear walls with shotcrete and/or the addition of new interior shear walls. Understandably, load paths must be provide to the new shear walls to transfer seismic

forces to them through them, and into the foundation soil.

Sheet 6 of 6

Figure D-4. Example of concrete building. (Sheet 6 of 6)